

ASSEMBLY INSTRUCTIONS

Ax1	Hx5
Bx1	Ix1
Cx2	Qx1
Dx1	Jx4 M8x20mm
Ex1	Kx3 M6x35mm
Fx1	Lx4 M8x30mm
Gx5	Mx4
Ox1	Nx4
	Px1

